



This DiSEqC switch is to connect up to four dishes into one receiver. Simply go into LNB setup in your receiver and for the first satellite select port 1 and for the second satellite select port 2 and the same for port 3 and 4. No power injector is required for this DiSEqC switch as the power is provided by the satellite receiver.

Specifications are subject to change without notice.

162 Chesterville Road, Moorabbin, Victoria 3189
Phone +61 3 9553 3399 Fax +61 3 9553 3393

www.satking.com.au